



MPG Handwheel Pendant

HARDWARE MANUAL

Revision 2.01



GLOBAL TECHNICAL SUPPORT

Go to the [Global Technical Support Portal](#) for information and support about your Aerotech, Inc. products. The website supplies software, product manuals, Help files, training schedules, and PC-to-PC remote technical support. If necessary, you can complete Product Return (RMA) forms and get information about repairs and spare or replacement parts. To get help immediately, contact a service office or your sales representative. Include your customer order number in your email or have it available before you call.

This manual contains proprietary information and may not be reproduced, disclosed, or used in whole or in part without the express written permission of Aerotech, Inc. Product names mentioned herein are used for identification purposes only and may be trademarks of their respective companies.

Copyright © 2009-2021, Aerotech, Inc., All rights reserved.



Table of Contents

MPG Handwheel Pendant	1
Table of Contents	3
List of Figures	5
List of Tables	7
EU Declaration of Conformity	9
Safety Procedures and Warnings	11
Chapter 1: Introduction	13
1.1. Mechanical Design	14
1.2. Environmental Specifications	15
Chapter 2: Installation and Configuration	17
2.1. MPG Connections	17
2.1.1. Connect the MPG to the Automation1 XC4/XC4e	19
2.1.2. Connect the MPG to the Automation1 XI4	22
2.1.3. Connect the MPG to the Automation1 XR3	25
Chapter 3: Operation Information	29
Chapter 4: Troubleshooting	31
4.1. Preventative Maintenance	32
Appendix A: Warranty and Field Service	33
Appendix B: Legacy Devices	35
B.1. Connecting the MPG	35
B.1.1. Connect the MPG to the HPe/HLe	35
B.1.2. Connect the MPG to the CP/CL	37
B.1.3. Connect the MPG to the MP/ML	39
B.1.4. Connect the MPG to the Nservo	41
B.1.5. Connect the MPG to the Npaq	43
B.1.6. Connect the MPG to the Epaq	45
B.1.7. Connect the MPG to the Epaq MR/Npaq MR	47
B.2. A3200 Configuration Information	49
B.2.1. Software Version 3.00.000 and Above	49
B.2.2. Software Version 2.55 or Lower	61
B.3. Ensemble Configuration Information	73
Appendix C: Revision History	87
Index	89

This page intentionally left blank.

List of Figures

Figure 1-1: Dimensions	14
Figure 2-1: DC Power Connections (BRAKE24-2 Option)	17
Figure 2-2: ESTOP Detail	18
Figure 2-3: Bypass Plug	18
Figure 2-4: MPG to XC4/XC4e Cable Drawing	20
Figure 2-5: XC4/XC4e Safety Device Connection Detail	21
Figure 2-6: MPG to XI4 Cable Drawing	23
Figure 2-7: Automation1 XI4 Safety Device Connection Detail	24
Figure 2-8: MPG to XR3 Cable Drawing	26
Figure 2-9: Automation1 XR3 Safety Device Connection Detail	27
Figure 3-1: Using the MPG	29
Figure B-1: MPG to HPe/HLe Cable Drawing	36
Figure B-2: MPG to CP/CL Cable Drawing	38
Figure B-3: MPG to MP/ML Cable Drawing	40
Figure B-4: MPG to Nservo Cable Drawing	42
Figure B-5: MPG to Npaq Cable Drawing	44
Figure B-6: MPG to Epaq Cable Drawing	46
Figure B-7: MPG to Epaq MR/Npaq MR Cable Drawing	48
Figure B-8: Opening the MPG Folder	49
Figure B-9: MPG Program Options	50
Figure B-10: Set the Correct Include File	51
Figure B-11: Assigning Axis Names	52
Figure B-12: Defining Incremental Distance	53
Figure B-13: Defining the MPG Handwheel Connection (Npaq example shown)	54
Figure B-14: Defining the MPG I/O Connection (Npaq example shown)	55
Figure B-15: Define Multiplier Switch Inputs (4.05.000 and MP/ML only)	56
Figure B-16: Save Program Changes	57
Figure B-17: Opening the Program Automation Page	58
Figure B-18: Configure Program Automation (MPG.Pgm)	59
Figure B-19: Completed Program Automation Configuration	59
Figure B-20: Opening the Sample Program (MPGSample.pgm)	60
Figure B-21: Opening the MPG Folder	61
Figure B-22: MPG Program Options	62
Figure B-23: Assigning Axis Names	63
Figure B-24: Defining Incremental Distance	64
Figure B-25: Defining the MPG Handwheel Connection (Npaq example shown)	65
Figure B-26: Defining the MPG I/O Connection (Npaq example shown)	66
Figure B-27: Save Program Changes	67
Figure B-28: Opening the Program Automation Page	68
Figure B-29: Configuring Program Automation	69
Figure B-30: Configure Program Automation (MPG_INCLUDE.Pgm)	69
Figure B-31: Configure Program Automation (MPG.Pgm)	70
Figure B-32: Completed Program Automation Configuration	70
Figure B-33: Reset to Activate Program Automation	71
Figure B-34: Confirm Reset Results	71
Figure B-35: Opening the Sample Program (MPG_Sample.Pgm)	72
Figure B-36: Opening the MPG Folder	73
Figure B-37: MPG Program Options	74

Figure B-38: Open the MPG_Include.abi Include File	75
Figure B-39: Assigning Axis Names	76
Figure B-40: Defining Handwheel scaling	77
Figure B-41: Defining the MPG Handwheel Connection	78
Figure B-42: Defining the MPG I/O Connection	79
Figure B-43: Save Program Changes	80
Figure B-44: Copying Files to the Controller	81
Figure B-45: Opening the Configuration Manager	82
Figure B-46: Select the Auto-Run Task parameters	83
Figure B-47: Configure the Auto-Run Task parameters	84
Figure B-48: Activating Task 2 and Task 3 on the controller	85
Figure B-49: Sending the new parameters and Resetting the controller	86

List of Tables

Table 1-1: Electrical Specifications	13
Table 2-1: XC4/XC4e Adapter Cable Connector Pinout	19
Table 2-2: XI4 Adapter Cable Connector Pinout	22
Table 2-3: XR3 Adapter Cable Connector Pinout	25
Table 4-1: Troubleshooting	31
Table 4-2: Preventative Maintenance	32
Table B-1: HPe/HLe Adapter Cable Connector Pinout	35
Table B-2: CP/CL Adapter Cable Connector Pinout	37
Table B-3: MP/ML Adapter Cable Connector Pinout	39
Table B-4: Nservo Adapter Cable Connector Pinout	41
Table B-5: Npaq Adapter Cable Connector Pinout	43
Table B-6: Epaq Adapter Cable Connector Pinout	45
Table B-7: MR Adapter Cable Connector Pinout	47

This page intentionally left blank.

EU Declaration of Conformity

Manufacturer Aerotech, Inc.
Address 101 Zeta Drive
Pittsburgh, PA 15238-2811
USA
Product MPG
Model/Types All

This is to certify that the aforementioned product is in accordance with the applicable requirements of the following directive(s):

2014/35/EU Low Voltage Directive

and has been designed to be in conformity with the applicable requirements of the following standard(s) when installed and used in accordance with the manufacturer's supplied installation instructions.

EN 61010-1:2010 Safety Requirements for Electrical Equipment
EN60947-5-5 Control circuit devices and switching elements

Authorized Representative



/ Simon Smith, European Director

Aerotech Ltd
The Old Brick Kiln, Ramsdell, Tadley
Hampshire RG26 5PR
UK

Engineer Verifying Compliance



/ Alex Weibel

Aerotech, Inc.
101 Zeta Drive
Pittsburgh, PA 15238-2811
USA
9/21/2021

Date



This page intentionally left blank.

Safety Procedures and Warnings



IMPORTANT: This manual tells you how to carefully and correctly use and operate the handwheel pendant.

- Read all parts of this manual before you install or operate the handwheel pendant or before you do maintenance to your system.
- To prevent injury to you and damage to the equipment, obey the precautions in this manual.
- All specifications and illustrations are for reference only and were complete and accurate as of the release of this manual. To find the newest information about this product, refer to www.aerotech.com.

If you do not understand the information in this manual, contact Aerotech Global Technical Support.



IMPORTANT:

This product has been designed for light industrial manufacturing or laboratory environments. If the product is used in a manner not specified by the manufacturer:

- The protection provided by the equipment could be impaired.
- The life expectancy of the product could be decreased.



WARNING: To prevent damage to the equipment and decrease the risk of electrical shock and injury, obey the precautions that follow.


1. Make sure that all system cables are correctly attached and positioned.
2. Do not use the cables or the connectors to lift or move this product.
3. Use this product only in environments and operating conditions that are approved in this manual.
4. Only trained operators should operate this equipment.

This page intentionally left blank.

Chapter 1: Introduction

The MPG (Manual Pulse Generator) input device for the A3200 and Ensemble provides the capability to manually fine-position up to six axes.

- Six axis selector switch (Axis Select)
- Three position distance multiplier switch, x1, x10 and x100 (Distance Multiplier)
- Emergency stop switch for user-provided ESTOP circuit (ESTOP)
- 400 count per revolution handwheel (100x4)
- User programmable from within AeroScript, AeroBasic, or a G-Code program
- Dead-man, thumb-operated safety switch (ENABLE)
- Programmatically activated (or manually from the software)



Refer to [Section 2.1](#) for connection information and Aerotech cable part numbers.

Table 1-1: Electrical Specifications

Description	MPG
5 VDC	Provided by the Automation1, A3200, or Ensemble drive
24 VDC	500 mA, supplied by the user or by Aerotech accessory: BRAKE24-2 (refer to Section 2.1 for DC Power Connections)



IMPORTANT: The user must provide a 24 VDC (500 mA) power supply.

1.1. Mechanical Design



IMPORTANT: All specifications and illustrations are for reference only and were complete and accurate as of the release of this manual. To find the newest information about this product, refer to www.aerotech.com.




Figure 1-1: Dimensions

1.2. Environmental Specifications

The environmental specifications for the MPG are listed below.

Ambient Temperature	Operating: 5° to 40°C (41° to 104° F)
	Storage: -20° to 70°C (-4° to 158° F)
Humidity	Maximum relative humidity is 80% for temperatures up to 31°C. Decreasing linearly to 50% relative humidity at 40°C. Non condensing.
Altitude	Up to 2000 meters.
Pollution	Pollution degree 2 (normally only non-conductive pollution).
Use	Indoor use only.

This page intentionally left blank.

Chapter 2: Installation and Configuration

2.1. MPG Connections

Each MPG adapter cable is labeled to identify the receiving connector on the drive.



IMPORTANT: The 7th axis position of the axis select switch is not supported.

DC Power Connections

The MPG requires 24 VDC at 500 mA. Power can be supplied through the BRAKE24-2 option (Figure 2-1) or a user-provided power supply. Refer to the drive sub-sections for specific wire colors.




Figure 2-1: DC Power Connections (BRAKE24-2 Option)

Emergency Stop Connections

The emergency stop (ESTOP) switch on the MPG can be connected in series with the user-supplied ESTOP and Safe Torque Off (STO) circuit. There are two normally-closed switch contacts: ESTOP NC1 and ESTOP NC2. Refer to drive hardware manual for ESTOP switch connection information. Refer to the drive sub-sections for specific wire colors.




Figure 2-2: ESTOP Detail

Aerotech provides an ESTOP bypass connector that you can connect to the adapter cable. The bypass plug will close the user’s ESTOP circuit and allow the machine to operate without the MPG.




Figure 2-3: Bypass Plug

2.1.1. Connect the MPG to the Automation1 XC4/XC4e

The drive (iXC4, XC4, iXC4e, or XC4e) must be equipped with the -IO option. Connect to the AUX I/O and DIGITAL IN 1 connectors and use digital input bits 0 through 8. The handwheel uses the auxiliary encoder input channel.

Table 2-1: XC4/XC4e Adapter Cable Connector Pinout

Connector	Pin	Description
DIGITAL IN 1	1	Common
	2	Input 0 (X Axis)
	3	Input 1 (Y Axis)
	4	Input 2 (Z Axis)
	5	Input 3 (4 Axis)
	6	Input Common
	7	Input 4 (5 Axis)
	8	Input 5 (6 Axis)
	9	Input 6 (x1 Distance Multiplier)
	10	Input 7 (x10 Distance Multiplier)
AUX I/O	17	Input 8 (x100 Distance Multiplier)
	10	Cosine
	11	Cosine-N
	12	5 V
	1	Sine
	2	Sine-N
	21	Common
24	Common	
To: User-Supplied Power Supply (Flying Leads)	RED	24 VDC
	BLK	Common
	GRN	ESTOP NC1
	BRN	ESTOP NC1
	ORN	ESTOP NC2
	YEL	ESTOP NC2
	GRN/WHT	To Frame Ground




Figure 2-4: MPG to XC4/XC4e Cable Drawing

The adapter cable that is supplied by Aerotech has wires (ESTOP NC1 and ESTOP NC2) that can be connected to a user-supplied safety device. To bypass the user-supplied safety device, connect the ESTOP NC1 and ESTOP NC2 labeled wires directly to the 24 V. Refer to [Figure 2-5](#).




Figure 2-5: XC4/XC4e Safety Device Connection Detail

2.1.2. Connect the MPG to the Automation1 XI4

The XI4 must be equipped with the -IO option. Connect to the AUX I/O and DIGITAL IN 1 connectors and use digital input bits 0 through 8. The handwheel uses the auxiliary encoder input channel.

Table 2-2: XI4 Adapter Cable Connector Pinout

Connector	Pin	Description
DIGITAL I/O	19	Input Common
	6	Input 0 (X Axis)
	20	Input 1 (Y Axis)
	7	Input 2 (Z Axis)
	21	Input 3 (4 Axis)
	8	Input Common
	22	Input 4 (5 Axis)
	9	Input 5 (6 Axis)
	23	Input 6 (x1 Multiplier)
	10	Input 7 (x10 Multiplier)
	11	High Speed Input + (x100 Multiplier)
	24	High-Speed Input -
AXIS	6	Auxiliary Cosine
	19	Auxiliary Cosine-N
	8	5 V
	5	Auxiliary Sine
	18	Auxiliary Sine-N
	21	Common
To: User-Supplied Power Supply (Flying Leads)	RED	24 VDC
	BLK	Common
	GRN	ESTOP NC1
	BRN	ESTOP NC1
	ORN	ESTOP NC2
	YEL	ESTOP NC2
	GRN/WHT	To Frame Ground

XI4 Pendant Interface Cable
 P/N: C26157-xx
 Refer to your installation device
 for a complete cable drawing.




Figure 2-6: MPG to XI4 Cable Drawing

The adapter cable that is supplied by Aerotech has wires (ESTOP NC1 and ESTOP NC2) that can be connected to a user-supplied safety device. To bypass the user-supplied safety device, connect the ESTOP NC1 and ESTOP NC2 labeled wires directly to the 24 V. Refer to [Figure 2-5](#).




Figure 2-7: Automation1 XI4 Safety Device Connection Detail

2.1.3. Connect the MPG to the Automation1 XR3

Connect to the Aux Encoder, DIN , and STO connectors and use digital input bits 0 through 8. The handwheel uses the second auxiliary encoder input channel.

Table 2-3: XR3 Adapter Cable Connector Pinout

Connector	Pin	Description
DIN	25	Key
	23	Input 0 (X Axis)
	22	Input 1 (Y Axis)
	21	Input 2 (Z Axis)
	20	Input 3 (4 Axis)
	18	Input 4 (5 Axis)
	17	Input 5 (6 Axis)
	16	Input 6 (x1 Multiplier Distance)
	15	Input 7 (x10 Multiplier Distance)
	12	Input 8 (x100 Multiplier Distance)
	19	Port 1 Input Common
	24	Port 0 Input Common
	13	Port 2 Input Common
AUX ENCODER	8	Cosine
	3	Cosine-N
	4	5 V
	1	Sine
	6	Sine-N
	2	Common
STO	6	STO 1-
	7	STO 2-
	1	STO 1+
	2	STO 2+
To: User-Supplied Power Supply (Flying Leads)	GRN/WHT	Ground
	WHT	ESTOP NC2
	GRN	ESTOP NC1
	PNK	24 VDC
	GRY	Common

XR3 Pendant Interface Cable
 P/N C26156-xx
 Refer to your installation device
 for a complete cable drawing.




Figure 2-8: MPG to XR3 Cable Drawing

The adapter cable that is supplied by Aerotech has wires (ESTOP NC1 and ESTOP NC2) that can be connected to a user-supplied safety device. To bypass the user-supplied safety device, connect the ESTOP NC1- and ESTOP NC2-labeled wires directly to the 24 V. Refer to [Figure 2-9](#).




Figure 2-9: Automation1 XR3 Safety Device Connection Detail

This page intentionally left blank.

Chapter 3: Operation Information

After configuring the controller for the MPG and enabling the MPG (for example, running the sample program) the MPG will be active.

With the MPG active:

1. Select an axis [**Axis Select** knob]
2. Set the distance increment [**Distance Multiplier** knob]
3. Depress the enable button [**ENABLE** button]



IMPORTANT: The ENABLE button acts as a "dead man switch" and must be depressed for the MPG to operate.

4. Rotate the Manual Pulse Generator [**Handwheel**] to manually fine tune position an axis.




Figure 3-1: Using the MPG

This page intentionally left blank.

Chapter 4: Troubleshooting

This section covers symptoms, probable causes, and solutions related to MPG operation.



WARNING: There are no user-serviceable parts inside of the MPG.



WARNING: Disconnect power before you do service to the MPG.



WARNING: Voltages must be mechanically secured before you apply power to the MPG.

Table 4-1: Troubleshooting

Symptom	Possible Cause and Solution
Axes will not move	Axes are not enabled or the controller is not correctly configured to run the required MPG.Pgm program
	Dead-man switch is not depressed

4.1. Preventative Maintenance

The MPG and external wiring should be inspected monthly. Inspections may be required at more frequent intervals depending on the environment and use of the system.



WARNING: All service and maintenance must be performed by qualified personnel.



WARNING: Do not use of this product in a manner other than its intended use.

Table 4-2: Preventative Maintenance

Check	Action to be Taken
Visually inspect MPG enclosure for loose or damaged parts / hardware. Note: Internal inspection is not required.	Parts should be repaired as required. If internal damage is suspected, these parts should be checked and repairs made if necessary.
Check for fluids or electrically conductive material exposure.	Any fluids or electrically conductive material must not be permitted to enter the MPG.
Visually inspect all cables and connections.	Tighten or re-secure any loose connections. Replace worn or frayed cables. Replace broken connectors.

Cleaning

The MPG enclosure can be wiped with a clean, dry, soft cloth. The cloth may be slightly moistened if required with water or isopropyl alcohol to aid in cleaning if necessary. In this case, be careful not to allow moisture to enter the MPG or onto exposed connectors / components. Fluids and sprays are not recommended because of the chance for internal contamination, which may result in electrical shorts and/or corrosion. The electrical power must be disconnected from the MPG while cleaning. Do not allow cleaning substances or other fluids to enter the MPG or to get on to any of the connectors. Cleaning labels should be avoided to prevent removing label information.

Appendix A: Warranty and Field Service

Aerotech, Inc. warrants its products to be free from harmful defects caused by faulty materials or poor workmanship for a minimum period of one year from date of shipment from Aerotech. Aerotech's liability is limited to replacing, repairing or issuing credit, at its option, for any products that are returned by the original purchaser during the warranty period. Aerotech makes no warranty that its products are fit for the use or purpose to which they may be put by the buyer, whether or not such use or purpose has been disclosed to Aerotech in specifications or drawings previously or subsequently provided, or whether or not Aerotech's products are specifically designed and/or manufactured for buyer's use or purpose. Aerotech's liability on any claim for loss or damage arising out of the sale, resale, or use of any of its products shall in no event exceed the selling price of the unit.

THE EXPRESS WARRANTY SET FORTH HEREIN IS IN LIEU OF AND EXCLUDES ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, BY OPERATION OF LAW OR OTHERWISE. IN NO EVENT SHALL AEROTECH BE LIABLE FOR CONSEQUENTIAL OR SPECIAL DAMAGES.

Return Products Procedure

Claims for shipment damage (evident or concealed) must be filed with the carrier by the buyer. Aerotech must be notified within thirty (30) days of shipment of incorrect material. No product may be returned, whether in warranty or out of warranty, without first obtaining approval from Aerotech. No credit will be given nor repairs made for products returned without such approval. A "Return Materials Authorization (RMA)" number must accompany any returned product(s). The RMA number may be obtained by calling an Aerotech service center or by submitting the appropriate request available on our website (www.aerotech.com). Products must be returned, prepaid, to an Aerotech service center (no C.O.D. or Collect Freight accepted). The status of any product returned later than thirty (30) days after the issuance of a return authorization number will be subject to review.

Visit [Global Technical Support Portal](#) for the location of your nearest Aerotech Service center.

Returned Product Warranty Determination

After Aerotech's examination, warranty or out-of-warranty status will be determined. If upon Aerotech's examination a warranted defect exists, then the product(s) will be repaired at no charge and shipped, prepaid, back to the buyer. If the buyer desires an expedited method of return, the product(s) will be shipped collect. Warranty repairs do not extend the original warranty period.

Fixed Fee Repairs - Products having fixed-fee pricing will require a valid purchase order or credit card particulars before any service work can begin.

All Other Repairs - After Aerotech's evaluation, the buyer shall be notified of the repair cost. At such time the buyer must issue a valid purchase order to cover the cost of the repair and freight, or authorize the product(s) to be shipped back as is, at the buyer's expense. Failure to obtain a purchase order number or approval within thirty (30) days of notification will result in the product(s) being returned as is, at the buyer's expense.

Repair work is warranted for ninety (90) days from date of shipment. Replacement components are warranted for one year from date of shipment.

Rush Service

At times, the buyer may desire to expedite a repair. Regardless of warranty or out-of-warranty status, the buyer must issue a valid purchase order to cover the added rush service cost. Rush service is subject to Aerotech's approval.

On-site Warranty Repair

If an Aerotech product cannot be made functional by telephone assistance or by sending and having the customer install replacement parts, and cannot be returned to the Aerotech service center for repair, and if Aerotech determines the problem could be warranty-related, then the following policy applies:

Aerotech will provide an on-site Field Service Representative in a reasonable amount of time, provided that the customer issues a valid purchase order to Aerotech covering all transportation and subsistence costs. For warranty field repairs, the customer will not be charged for the cost of labor and material. If service is rendered at times other than normal work periods, then special rates apply.

If during the on-site repair it is determined the problem is not warranty related, then the terms and conditions stated in the following "On-Site Non-Warranty Repair" section apply.

On-site Non-Warranty Repair

If any Aerotech product cannot be made functional by telephone assistance or purchased replacement parts, and cannot be returned to the Aerotech service center for repair, then the following field service policy applies:

Aerotech will provide an on-site Field Service Representative in a reasonable amount of time, provided that the customer issues a valid purchase order to Aerotech covering all transportation and subsistence costs and the prevailing labor cost, including travel time, necessary to complete the repair.

Service Locations

<http://www.aerotech.com/contact-sales.aspx?mapState=showMap>

USA, CANADA, MEXICO

Aerotech, Inc.
Global Headquarters

CHINA

Aerotech China
Full-Service Subsidiary

GERMANY

Aerotech Germany
Full-Service Subsidiary

TAIWAN

Aerotech Taiwan
Full-Service Subsidiary

UNITED KINGDOM

Aerotech United Kingdom
Full-Service Subsidiary

Appendix B: Legacy Devices

B.1. Connecting the MPG

B.1.1. Connect the MPG to the HPe/HLe

The HPe or HLe must be equipped with the -IO option. Connect to the J205 (Auxiliary I/O) and TB305 (I/O) connectors and use digital input bits 0 through 8. The handwheel uses the auxiliary encoder input channel.

Table B-1: HPe/HLe Adapter Cable Connector Pinout

Connector	Pin	Description
TB305 [DIGITAL IN]	1	Common
	2	Input 0 (X Axis)
	3	Input 1 (Y Axis)
	4	Input 2 (Z Axis)
	5	Input 3 (4 Axis)
	6	Input 4 (5 Axis)
	7	Input 5 (6 Axis)
	8	NDRIVE: Input 6 (x1 Distance Multiplier) ENSEMBLE: Input 6 (x10 Distance Multiplier)
	9	NDRIVE: Input 7 (x10 Distance Multiplier) ENSEMBLE: Input 7 (x100 Distance Multiplier)
	10	Ground
J205 [AUX I/O]	17	NDRIVE: Input 8 (x100 Distance Multiplier) ENSEMBLE: N/C
	10	Cosine
	11	Cosine-N
	12	5 V
	1	Sine
	2	Sine-N
	21	Common
	24	Common
To: User-Supplied Power Supply (Flying Leads)	RED	24 VDC
	BLK	Common
	GRN	ESTOP NC1
	BRN	ESTOP NC1
	ORN	ESTOP NC2
	YEL	ESTOP NC2
	GRN/YEL	To Frame Ground

HPe/HLe Pendant Interface Cable
 P/N: C22672-xx (for Ndrive)
 P/N: C23272-xx (for Ensemble)
 Refer to your installation device
 for a complete cable drawing.




Figure B-1: MPG to HPe/HLe Cable Drawing

B.1.2. Connect the MPG to the CP/CL

The CP or CL must be equipped with the -IO option. Connect to the Auxiliary I/O (CP: J104; CL: J105) and TB204 (I/O) connectors and use digital input bits 0 through 8. The handwheel uses the auxiliary encoder input channel.

Table B-2: CP/CL Adapter Cable Connector Pinout

Connector	Pin	Description
TB204 [DIGITAL IN]	1	Common
	2	Input 0 (X Axis)
	3	Input 1 (Y Axis)
	4	Input 2 (Z Axis)
	5	Input 3 (4 Axis)
	6	Input 4 (5 Axis)
	7	Input 5 (6 Axis)
	8	NDRIVE: Input 6 (x1 Distance Multiplier) ENSEMBLE: Input 6 (x10 Distance Multiplier)
	9	NDRIVE: Input 7 (x10 Distance Multiplier) ENSEMBLE: Input 7 (x100 Distance Multiplier)
	10	Ground
CL: J105 [AUX I/O]	17	NDRIVE: Input 8 (x100 Distance Multiplier) ENSEMBLE: N/C
	10	Cosine
CP: J104 [AUX I/O]	11	Cosine-N
	12	5 V
	1	Sine
	2	Sine-N
	21	Common
	24	Common
To: User-Supplied Power Supply (Flying Leads)	RED	24 VDC
	BLK	Common
	GRN	ESTOP NC1
	BRN	ESTOP NC1
	ORN	ESTOP NC2
	YEL	ESTOP NC2
	GRN/YEL	To Frame Ground

CP/CL Pendant Interface Cable
 P/N: C22671-xx (for Ndrive)
 P/N: C23271-xx (for Ensemble)
 Refer to your installation device
 for a complete cable drawing.




Figure B-2: MPG to CP/CL Cable Drawing

B.1.3. Connect the MPG to the MP/ML

The MP or ML must be equipped with the -IO option. Connect to the J201 (Auxiliary I/O) and TB203 (I/O) connectors and use digital input bits 0 through 7. The handwheel uses the auxiliary encoder input channel.

Table B-3: MP/ML Adapter Cable Connector Pinout

Connector	Pin	Description
TB203 [DIGITAL IN]	1	Common
	2	Input 0 (X Axis)
	3	Input 1 (Y Axis)
	4	Input 2 (Z Axis)
	5	Input 3 (4 Axis)
	6	Input 4 (5 Axis)
	7	Input 5 (6 Axis)
	8	Input 6 (x10 Distance Multiplier)
	9	Input 7 (x100 Distance Multiplier)
	10	Common
Ndrive: BB-MP/ML Module TB1	TB1-1	Sine
	TB1-2	Sine-N
	TB1-3	Cosine
	TB1-4	Cosine-N
	TB1-7	5 VDC
	TB1-8	Common
Ensemble J201 [AUX I/O]	2	Cosine
	7	Cosine-N
	4	5 VDC
	1	Sine
	6	Sine-N
	9	Common
Ndrive To: User-Supplied Power Supply (Flying Leads)	RED	24 VDC
	BLK	Common
	GRN	ESTOP NC1
	BRN	ESTOP NC1
	ORN	ESTOP NC2
	YEL	ESTOP NC2
	GRN	To Frame Ground
Ensemble To: User-Supplied Power Supply (Flying Leads)	RED	24 VDC
	BLK	Common
	GRN	ESTOP NC1
	BRN	ESTOP NC1
	ORN	ESTOP NC2
	YEL	ESTOP NC2
	GRN/WHT	To Frame Ground




Figure B-3: MPG to MP/ML Cable Drawing

B.1.4. Connect the MPG to the Nservo

Connect to the J107 (Auxiliary Encoder), J108 (Digital Outputs), J109 (Digital Inputs) and J110 (PSO/Brake) connectors and use digital input bits 0 through 7 and 12. The handwheel uses the auxiliary encoder input channel on J107.

Table B-4: Nservo Adapter Cable Connector Pinout

Connector	Pin	Color	Description
J107 [ESTOP and Extra Encoder Channel]	AUXSIN+	ORN	Sine
	AUXSIN-	WHT/ORN	Sine-N
	AUXCOS+	RED	Cosine
	AUXCOS-	WHT/RED	Cosine-N
	UINT+	WHT/GRY	x100 Distance Multiplier
	UINT-	WHT	Common
J109 [OPTO InputS]	0	BLK	X Axis
	1	YEL/BLK	Y Axis
	2	BLU	Z Axis
	3	BLU/BLK	4 Axis
	4	YEL	5 Axis
	5	WHT/YEL	6 Axis
	6	GRY/BLK	x1 Distance Multiplier
	7	GRY/RED	x10 Distance Multiplier
	C	BLK/ORN	Common
J110 [PSO and BRAKE]	+5 VDC	VIO and WHT/VIO	+5 VDC
	ND	WHT/GRN and GRN	Common
To: User-Supplied Power Supply (Flying Leads)	RED		24 VDC
	BLK		Common
	GRN		ESTOP NC1
	BRN		ESTOP NC1
	ORN		ESTOP NC2
	YEL		ESTOP NC2
	GRN/YEL		To Frame Ground




Figure B-4: MPG to Nservo Cable Drawing

B.1.5. Connect the MPG to the Npaq

Connect to the J8 (High Speed I/O), J9 (I/O) and J12 (Misc. I/O) connectors and use digital input bits 0 through 7 and 12. The handwheel uses the second auxiliary encoder input channel.

Table B-5: Npaq Adapter Cable Connector Pinout

Connector	Pin	Description
J9 [I/O]	15	Input 0 (X Axis)
	16	Input 1 (Y Axis)
	17	Input 2 (Z Axis)
	18	Input 3 (4 Axis)
	19	Input 4 (5 Axis)
	20	Input 5 (6 Axis)
	21	Input 6 (x1 Multiplier Distance)
	22	Input 7 (x10 Multiplier Distance)
	14	Common
J12 [Misc. I/O]	12+	Input 8 (x100 Multiplier Distance)
	12-	Common
J8 [High Speed I/O]	15	Cosine
	16	Cosine-N
	25	5 VDC
	13	Sine
	14	Sine-N
	24	Common
To: User-Supplied Power Supply (Flying Leads)	RED	24 VDC
	BLK	Common
	GRN	ESTOP NC1
	BRN	ESTOP NC1
	ORN	ESTOP NC2
	YEL	ESTOP NC2
	GRN/YEL	To Frame Ground

Npaq Pendant Interface Cable
 P/N C22673-xx
 Refer to your installation device
 for a complete cable drawing.




Figure B-5: MPG to Npaq Cable Drawing

B.1.6. Connect the MPG to the Epaq

Connect to the Opto-In, and the Auxiliary Encoder connectors and use digital input bits 0 through 7. The handwheel uses an auxiliary encoder input channel.

Table B-6: Epaq Adapter Cable Connector Pinout

Connector	Pin	Description
Digital Inputs	1	Common
	2	Input 0 (X Axis)
	3	Input 1 (Y Axis)
	4	Input 2 (Z Axis)
	5	Input 3 (4 Axis)
	6	Input 4 (5 Axis)
	7	Input 5 (6 Axis)
	8	Input 6 (x10 Distance Multiplier)
	9	Input 7 (x100 Distance Multiplier)
	10	Common
Aux Encoder	2	Cosine
	7	Cosine-N
	4	5 VDC
	1	Sine
	6	Sine-N
	9	Common
To: User-Supplied Power Supply Flying Leads	RED	24 VDC
	BLK	Common
	GRN	ESTOP NC1
	BRN	ESTOP NC1
	ORN	ESTOP NC2
	YEL	ESTOP NC2
	GRN/YEL	To Frame Ground




Figure B-6: MPG to Epaq Cable Drawing

B.1.7. Connect the MPG to the Epaq MR/Npaq MR

Connect to the Digital/Analog I/O, and the Auxiliary Encoder connectors and use digital input bits 0 through 7. The handwheel uses an auxiliary encoder input channel.

Table B-7: MR Adapter Cable Connector Pinout

Connector	Pin	Description
DIGITAL/ANALOG I/O	4	Common
	16	Common
	5	Input 0 (X Axis)
	6	Input 1 (Y Axis)
	7	Input 2 (Z Axis)
	8	Input 3 (4 Axis)
	17	Input 4 (5 Axis)
	18	Input 5 (6 Axis)
	19	Input 6 (x10 Distance Multiplier)
	20	Input 7 (x100 Distance Multiplier)
AUX ENCODER	2	Cosine
	7	Cosine-N
	4	5 VDC
	1	Sine
	6	Sine-N
	9	Common
	5	Common
To: User-Supplied Power Supply (Flying Leads)	RED	24 VDC
	BLK	Common
	GRN	ESTOP NC1
	BRN	ESTOP NC1
	ORN	ESTOP NC2
	YEL	ESTOP NC2
	GRN/YEL	To Frame Ground

MR Pendant Interface Cable
 P/N C23278-xx (for Epaq MR and Npaq MR)
 Refer to your installation device
 for a complete cable drawing.




Figure B-7: MPG to Epaq MR/Npaq MR Cable Drawing

B.2. A3200 Configuration Information

The MPG configuration details for the A3200 controller vary based upon the version of software which your controller is running.

B.2.1. Software Version 3.00.000 and Above



IMPORTANT: This configuration is applicable for customers that have installed software version 3.00.000 or higher. Refer to [Section B.2.2.](#) if you have a software version lower than 3.00.000.

The MPG requires an AeroBasic program running on a secondary task to monitor the MPG switches and command the axes to move when the user rotates the manual pulse generator (MPG or handwheel). This program and other required files are distributed with the Automation 3200 software. They can be found in the \Program Files\A3200\Samples\AeroBasic\MPG folder.




Figure B-8: Opening the MPG Folder

The MPG.pgm program controls the MPG and includes either the MPGMultipleAxisInclude.pgm or the MPGSingleAxisInclude.pgm file. MPGMultipleAxisInclude.pgm and MPGSingleAxisInclude.pgm define the parameters by which the MPG operates. The MPGInclude.pgm file sets global variables to allow the system to recognize the MPG. The MPGSample.pgm shows a sample of how the MPG can be used.




Figure B-9: MPG Program Options

The following steps will show how to configure the MPG.pgm, select the single or multiple axis include file, add the MPGInclude.pgm and MPG.pgm to program automation, and will also show how to open the sample program (MPGSample.pgm).

Open the MPG.Pgm and the appropriate include file. If you have the MPG connected to an Npaq or Nservo then you should open the MPGMultipleAxisInclude.pgm. If you have the MPG connected to an HLe, HPe, CP, CL, MP, or ML then open the MPGSingleAxisInclude.pgm.

Modify the MPG.pgm file to reference the appropriate include file. By default MPG.pgm includes the MPGSingleAxisInclude.pgm.




Figure B-10: Set the Correct Include File

Step 1:

Modify the first six lines of the program beginning with "#define", changing the second column of axis names to match the names of the axes in your system.




Figure B-11: Assigning Axis Names

Step 2:

Define the distance (metric) of an axis move equal to one tick of the handwheel.



WARNING: If this distance is too large, Position Errors or other faults will occur as the axis motion is commanded by the MPG.

The screenshot displays the A3200 Motion Composer software. The top section, 'Axis Manager', shows four axes (X, Y, Z, U) with their respective control buttons and status indicators. The bottom section is a code editor showing the following G-code:

```
27
28 * define the distance for
29 * distance is in primary u
30 #DEFINE BaseIncr .005
31
32 * Define which axis's enc
33 #DEFINE EncCh Y
34
35 * !!!!!!! DIFFERENCE BETWEEN NPAQ and NSERVO !!!!!!!
36 *
37 * Change the axis defined for IOAxis as follows:
38 * For Npaq this should be the name of the first axis
39 * For Nservo this should be the name of the axis connected to the MPG
40 #DEFINE IOAxis X
41
42 * Define inputs/state for the 6 axis switches
43 #DEFINE Xin $DI[0].IOAxis EQ 1
44 #DEFINE Yin $DI[1].IOAxis EQ 1
45 #DEFINE Zin $DI[2].IOAxis EQ 1
46 #DEFINE Uin $DI[3].IOAxis EQ 1
```

A red box highlights the line `#DEFINE BaseIncr .005`. A callout box points to this line with the text: "Define the smallest increment of an axis move. This distance will be equal to one tick of the handwheel."

Figure B-12: Defining Incremental Distance

Step 3:

Define the name of the axis that the MPG handwheel is connected to.



IMPORTANT: If connecting an MPG to an Npaq, the A3200 controller will expect the encoder channel of the MPG to be connected to the second auxiliary encoder channel of the Npaq (typically designated as the Y axis).

The screenshot displays the A3200 Motion Composer software. The top section shows the Axis Manager with axes X, Y, Z, and U. The Y axis is highlighted. The bottom section shows a code editor with a configuration file named 'MPGMultipleAxisInclude.pgm'. A red box highlights a comment in the code: 'If you are connecting to an Npaq, the A3200 system will expect the EncCh (encoder channel) of the MPG to be connected to the second Auxiliary Encoder Channel on the Npaq (typically the Y axis).'. The code defines parameters for the MPG, including BaseIncr, EncCh, IOAxis, and inputs for the 6 axis switches.

```

27
28 ' define the distance for one tick (or change) of the MPG handWheel
29 ' distance is in primary units which defaults to mm
30 #DEFINE BaseIncr .001
31
32 ' Define which axis'
33 #DEFINE EncCh Y
34
35 ' !!!!!!!!! DIFFERENC
36 '
37 ' Change the axis defined for IOAxis as follows:
38 ' For Npaq this should be the name of the first axis
39 ' For Nservo this should be the name of the axis connected to the MPG
40 #DEFINE IOAxis X
41
42 ' Define inputs/state for the 6 axis switches
43 #DEFINE Xin $DI[0].IOAxis EQ 1
44 #DEFINE Yin $DI[1].IOAxis EQ 1
45 #DEFINE Zin $DI[2].IOAxis EQ 1
46 #DEFINE Uin $DI[3].IOAxis EQ 1

```

Figure B-13: Defining the MPG Handwheel Connection (Npaq example shown)

Step 4:

Define the name of the axis that the MPG I/O is connected to.



IMPORTANT: If connecting an MPG to an Npaq, the A3200 controller will expect the I/O of the MPG to be connected to the first axis of the Npaq (typically designated as the X axis).




Figure B-14: Defining the MPG I/O Connection (Npaq example shown)

Step 5:



IMPORTANT: This step is only for users running software version 4.05.000 and have the MPG connected to an Ndrive MP or Ndrive ML.

Define the inputs for the three multiplier switches in the MPGSingelAxisInclude.pgm.

```

Task 1 Task 2 Task 3 Task 4 Task 5 Task 6 Task 7 Task 8 Task 9 Task 10 Task 11 Task 12 Task 13 Task 14 T
MPG.pgm MPGSingelAxisInclude.pgm
28 #DEFINE W B
29
30 ' Define the distance for one tick (or change) of the MPG handWheel.
31 ' The distance is in primary units which defaults to mm.
32 #DEFINE BaseIncr .005
33
34 ' This is the name of the axis that is connected to the auxiliary
35 ' encoder channel of the MPG Master axis.
36 #DEFINE EncCh X
37
38 ' This is the name of the axis that is connected to the MPG.
39 #DEFINE IOAxis X
40
41 ' Define the inputs/state for the 6 axis switches.
42 #DEFINE Xin $DI[0].IOAxis EQ 1
43 #DEFINE Yin $DI[1].IOAxis EQ 1
44 #DEFINE Zin $DI[2].IOAxis EQ 1
45 #DEFINE Uin $DI[3].IOAxis EQ 1
46 #DEFINE Vin $DI[4].IOAxis EQ 1
47 #DEFINE Win $DI[5].IOAxis EQ 1
48
49 ' Define the inputs/state for the 3 mult. switches.
50 #DEFINE MultX1 $DI[6].IOAxis EQ 1
51 #DEFINE MultX10 $DI[7].IOAxis EQ 1
52 #DEFINE MultX100 $DI[8].IOAxis EQ 1
53
54 ' The following defines are only valid for an Ndrive MP or ML.
55 #DEFINE MultX1 (($DI[6].IOAxis EQ 0) && ($DI[7].IOAxis EQ 0))
56 #DEFINE MultX10 $DI[6].IOAxis EQ 1
57 #DEFINE MultX100 $DI[7].IOAxis EQ 1
58
59 #DEFINE LedOutput $DO[10].IOAxis

```

Figure B-15: Define Multiplier Switch Inputs (4.05.000 and MP/ML only)

Step 6:

Save any changes made to each file by selecting the file and clicking the save button on the toolbar. The Save All option (located in the File menu) can also be used. After saving, these files can be closed.




Figure B-16: Save Program Changes

Step 7:

Open the Program Automation folder under the controller node in the Network Explorer. The Network Explorer can be pinned to the page to see the changes being made to Program Automation. Right click on the Program Automation folder and select Add... to bring up the Program Automation dialog.




Figure B-17: Opening the Program Automation Page

Step 8:

Add the MPG.pgm to the Program Automation Page by clicking the Browse... button. The MPG folder should be selected, but if not, navigate to it and select/open the MPG.pgm file.

Set the Mode to RunSilent and set the Task to "Task 2". This will start the MPG.pgm program running in Task 2 after initializing the A3200. Click OK when complete.




Figure B-18: Configure Program Automation (MPG.Pgm)

You will now see this file listed under the Programs folder in the Network Explorer.




Figure B-19: Completed Program Automation Configuration

Step 9:

Reset the SMC by clicking the Reset button in the Axis Manager (pictured below) or by selecting Reset from the Controller menu.

After the Reset routine has completed, run the MPGSample.pgm by opening it in Task 1 and then clicking the run button. The code within MPGSample.pgm can be used as an example of how to interface with the MPG from your own program.

If you switch to Task 2, notice that the MPG program is already running in that task.




Figure B-20: Opening the Sample Program (MPGSample.pgm)

B.2.2. Software Version 2.55 or Lower



IMPORTANT: This configuration is applicable for customers that have installed software version 2.55 or lower. Refer to [Section B.2.1](#), if you have a software version 3.00.000 or higher.

The MPG requires a CNC G-Code program running on a secondary task to monitor the MPG switches and command the axes to move when the user rotates the manual pulse generator (MPG or handwheel). This program and other required files are distributed with the A3200 software. They can be found in the \A3200\Samples\Gcode\MPG folder.




Figure B-21: Opening the MPG Folder

There are six sub-folders within the MPG folder. Four sub-folders contain variations of the MPG.Pgm program required for the four models of the MPG. The MPG.Pgm defines the parameters by which the handwheel operates. The Include sub-folder contains MPG_INCLUDE.Pgm. The MPG_INCLUDE.Pgm sets global variables to allow the system to recognize the MPG.




Figure B-22: MPG Program Options

The following steps will show how to configure the MPG.Pgm, add the MPG_Include.Pgm and MPG.Pgm into program automation, and will also show how to open the sample program (MPG_SAMPLE.Pgm).

Step 1:

Open the MPG.Pgm for the model of your MPG (Npaq, Nservo, HPe, HLe, or CP/CL), from the appropriate sub-folder.

Modify the first six lines of the program beginning with "#define", changing the second column of axis names to match the names of the axes in your system.




Figure B-23: Assigning Axis Names

Step 2:

Define the distance (metric) of an axis move equal to one tick of the handwheel.



WARNING: If this distance is too large, Position Errors or other faults will occur as the axis motion is commanded by the MPG.




Figure B-24: Defining Incremental Distance

Step 3:

Define the name of the axis that the MPG handwheel is connected to.



IMPORTANT: If connecting an MPG to an Npaq, the A3200 controller will expect the encoder channel of the MPG to be connected to the second auxiliary encoder channel of the Npaq (typically designated as the Y axis).




Figure B-25: Defining the MPG Handwheel Connection (Npaq example shown)

Step 4:

Define the name of the axis that the MPG I/O is connected to.



IMPORTANT: If connecting an MPG to an Npaq, the A3200 controller will expect the I/O of the MPG to be connected to the first axis of the Npaq (typically designated as the X axis).




Figure B-26: Defining the MPG I/O Connection (Npaq example shown)

Step 5:

Save any program changes before continuing and then return to the Nview HMI home page.




Figure B-27: Save Program Changes

Step 6:

Open the Program Automation page. From the main screen of the Nview HMI, select F7-Setup page, then select F8-Program Automation.



Figure B-28: Opening the Program Automation Page

Step 7:

Add the MPG_INCLUDE.Pgm to the Program Automation Page file list by pressing the F7-Add button (Figure 2-30). The Add button will open the **Auto Program Setup** dialog box (Figure 2-31).




Figure B-29: Configuring Program Automation

Navigate to the "C:\A3200\Samples\Gcode\MPG\Include" folder and select/open the MPG_Include.Pgm file.

Set the Execute Type field to "Auto Include" and set the Task of Execution to all tasks (check all task boxes). Click F3-Ok, when complete.



Figure B-30: Configure Program Automation (MPG_INCLUDE.Pgm)

Step 8:

Add the MPG.Pgm to the Program Automation Page.

Open the **Auto Program Setup** dialog box (Figure B-31).

Navigate to the “C:\A3200\Samples\Gcode\MPG” folder and select the MPG.Pgm based on the model of the MPG (choose from Ndrive HPe/HLe, Npaq, Nservo, and Ndrive CP/CL).

Set the Execute Type field to “Auto Run - Silent” and set the Task of Execution to “Task 2” (add a check mark to Task 2). Click F3-Ok, when complete.




Figure B-31: Configure Program Automation (MPG.Pgm)

When complete, the Program Automation should have two new entries similar to those highlighted in Figure B-32.




Figure B-32: Completed Program Automation Configuration

Step 9:

Press the "ESC" button to return to the main page of the Nview HMI. When prompted to Reset, select Yes.



Figure B-33: Reset to Activate Program Automation

Step 10:

After the Reset routine has completed, run the MPG_SAMPLE.Pgm.




Figure B-34: Confirm Reset Results




Figure B-35: Opening the Sample Program (MPG_Sample.Pgm)

B.3. Ensemble Configuration Information

The MPG requires two AeroBasic programs running on secondary tasks to monitor the MPG switches and activate gearing to move the axes when the user rotates the manual pulse generator (MPG or handwheel). These two programs and other required files are distributed with the Ensemble software. They can be found in the \Program Files\Ensemble\Samples\AeroBasic\MPG folder.




Figure B-36: Opening the MPG Folder

The MPG.ab program monitors the MPG and includes the MPG_Include.ab file. MPG_Include.ab defines the parameters by which the MPG operates. The MPG_Include.ab file defines global variables that allow the user program to activate the MPG. The MPG_Sample.ab program illustrates a sample of how the MPG can be used in a user's program.




Figure B-37: MPG Program Options

The following steps will show how to configure the MPG_Include.ab file and add the MPG.ab and MPG_Gear.ab programs to automatically run on the controller, as well as how to open the sample program (MPG_Sample.ab).

Step 1:

Open the MPG_Include.abi include file.




Figure B-38: Open the MPG_Include.abi Include File

Step 2:

Modify lines 5-10 of the program beginning with “#define”, changing the 0-5 numbers in the last column to -1, for any switch position of the MPG which will not command an axis to move.




Figure B-39: Assigning Axis Names

Modify lines 13-18 of the program beginning with “#define”, changing the 0-5 numbers in the last column to define which axis number will be commanded to move by the six switch positions. Note that axis numbers are 0-based, so the first axis (typically X) will be represented by 0, the second axis (typically Y) would be 1, etc.

Step 3:

Define the number of encoder counts to move the axis, per tick (or change) of the handwheel.



WARNING: If this distance is too large, Position Errors or other faults will occur as the axis motion is commanded by the MPG.

The screenshot shows the Ensemble Motion Composer (3.03.000) interface. The main window displays a code editor with the following configuration:

```

14 define Axis_Y 1 ; 2nd position on axis selector switch is axis
15 define Axis_Z 2 ; 3rd position on axis selector switch is axis
16 define Axis_4 3 ; 4th position on axis selector switch is axis
17 define Axis_5 4 ; 5th position on axis selector switch is axis
18 define Axis_6 5 ; 6th position on axis selector switch is axis
19
20 ; dglobal register assignments
21 define Multiplier 0
22 define Slave 1
23 define GearOn 2
24 define MPG_On 3
25
26 ; define the distance for one tick (or change) of the MPG handWheel
27 define BaseIncr 1 ; counts per tick
28
29 ; Change the Y below to the name of the axis in the Epaq, which the
30 ; Be sure to use the correct upper/lower case of the axis name !
31 define EncCh 1 ; Master axis's auxiliary encode
32
33 ; Change the X below to the name of the first axis in the Epaq, whi
34 ; Be sure to use the correct upper/lower case of the axis name !
35 define IOAxis 1
    
```

The right-hand side of the interface shows diagnostic data for both axes:

Property	X	Y
Position Co...	5866113 cnt	10753143.4...
Position Fe...	5866113 cnt	10753143 cnt
ProgramPosi...	5866113 cnt	10753143.4...

Property	X	Y
CW Limit In...	Hi	Hi
CCW Limit I...	Hi	Hi
Home Limit...	Hi	Hi

Property	X	Y
Position Er...	No	No
Over Curren...	No	No
CW End of T...	No	No

Property	X	Y
CWLimitActive	No	No
CCWLimitActive	No	No
Axis Enabled	Yes	Yes

Figure B-40: Defining Handwheel scaling

Step 4:

Define the 0-based axis index of the axis that the MPG handwheel is connected to.




Figure B-41: Defining the MPG Handwheel Connection

Step 5:

Define the 0-based axis index of the axis that the MPG I/O is connected to.




Figure B-42: Defining the MPG I/O Connection

Step 6:

Save changes made to the file by clicking the save button on the toolbar, then close the file.




Figure B-43: Save Program Changes

Step 7:

From within the Network Explorer of the HMI, drag the MPG.bcx file and the MPG_Gear.bcx files from the User Files to the File System on the controller to copy them to the controller.




Figure B-44: Copying Files to the Controller

Step 8:

Open the Configuration Manager from the Tools Menu




Figure B-45: Opening the Configuration Manager

Step 9:

Retrieve the parameters from the controller and click the plus-sign symbol to the left, to expand the parameters and then select the Task parameters, so they are visible on the right side of the screen. Select the AutoRunProgram parameter for task 2 on the right side of the screen and then select the File Lookup button in the Editor area of the screen.




Figure B-46: Select the Auto-Run Task parameters

Step 10:

Select MPG.bcx for the Task 2 AutoRunProgram and repeat Step 7 to select MPG_Gear.bcx for the Task 3 AutoRunProgram task parameters.




Figure B-47: Configure the Auto-Run Task parameters

Step 11:

Highlight the System parameters then select the TaskExecutionSetup parameter on the right side of the screen in the Viewer. Now Check the Task 2 and Task 3 checkboxes in the Editor area of the screen in the lower left.




Figure B-48: Activating Task 2 and Task 3 on the controller

Step 12:

Click the right mouse button on the controller name and select Send Parameters, then click the Reset Controller w/Auto-Run button.




Figure B-49: Sending the new parameters and Resetting the controller

Step 13:

After the Reset routine has completed, open and run the MPG_Sample.ab program on Task 1. The MPG_Sample.ab program illustrates how to enable the MPG from within a user program.

Appendix C: Revision History

Revision	Description
2.01	<ul style="list-style-type: none">• added XI4 connection information• moved legacy device information to Appendix B.
2.00	General Updates Section 2.1. <ul style="list-style-type: none">• added XC4/XC4e connection information• added XR3 connection information
1.05	Revision changes have been archived. If you need a copy of this revision, contact AerotechGlobal Technical Support.
1.04	
1.03	
1.02	
1.01	
1.00	

This page intentionally left blank.

Index

		ESTOP	18
		H	
		Handwheel	29
		Humidity	15
		I	
		inspect all cables and connections	32
		Installation and Configuration	17
		Introduction	13
		M	
		Mechanical Design	14
		ML	39
		MP	39
		MR	47
		N	
		Npaq	43
		Nservo	41
		O	
		Overview	13
		P	
		Pollution	15
		Possible Cause and Solution	31
		Power Connections	17
		Preventative Maintenance	32
		R	
		Revision History	87
		S	
		Safety Procedures and Warnings	11
		Software Version 2.55 or Lower	61
		Software Version 3.00.000	49
		Symptom	31
		T	
		Table of Contents	3
2			
2.55	61		
2014/35/EU	9		
3			
3.00.000	49		
A			
adapter cable	17		
Altitude	15		
Ambient Temperature	15		
Automation 3200 Configuration Information	49		
Axes will not move	31		
Axis Select	29		
B			
BRAKE24-2	17		
C			
Cable Drawing	17		
Check for fluids or electrically conductive material exposure	32		
CL	37		
Cleaning	32		
Connecting the MPG	17		
CP	37		
D			
DC Power Connections	17		
Declaration of Conformity	9		
dimensions	14		
Distance Multiplier	29		
E			
Emergency Stop Connections	18		
ENABLE	29		
Ensemble Configuration Information	73		
Environmental Specifications	15		
Epaq	45		
Epaq MR	47		

Troubleshooting 31

U

Use 15

W

Warranty and Field Service 33