

# Mechanical Bearing, Ball-Screw Stage PR0190SL

## **Precise & Robust Linear Motion for All**

The PRO190SL provides an optimal balance of positioning performance, payload capacity and size. Equipped with larger, stiffer bearings, PRO190SL delivers considerable load-carrying improvements and enhanced geometric performance compared to PRO165SL. Plus, PRO190SL features a smaller footprint and lower mass than the larger PRO225SL. Combining superior craftsmanship with the highest quality components, PRO190SL stages consistently and reliably deliver best-in-class positioning performance.

# **Key Applications**

PRO190SL mechanical bearing, ball-screw stages are extremely versatile, trusted and proven in medium- and high-performance applications, such as:

- Laser material processing
- Precision metrology, inspection & microscopy
- Electronics & circuit board manufacturing & inspection
- Display processing
- Synchrotron & light source experiments
- Medical device manufacturing
- Semiconductor fabrication
- Fiber optics & silicon photonics processing
  - Additive manufacturing & precision assembly



### **KEY FEATURES:**

- Offers an OPTIMAL BALANCE OF POSITIONING PERFORMANCE, LOAD CAPACITY & SIZE
- BEST-IN-CLASS GEOMETRIC PERFORMANCE ensures superior workpoint accuracy
- EXCELLENT MOTION & POSITIONING PERFORMANCE in a cost-effective package
- Rugged, reliable construction is ideal for VERSATILE INDUSTRIAL USE
- Hardcover & side seals offer
  PROTECTION AGAINST
  CONTAMINATION & PARTICULATES
- VACUUM- & CLEANROOM-COMPATIBLE versions available

#### **PR0190SL SPECIFICATIONS**

Mechanical Specifications			PR0190SL						
Travel		100	150	200	300	400	500	600	
Accuracy <sup>(1)</sup>	Standard	±6 μm	±7 μm	±8 μm	±9.5 µm	±11 μm	±13 μm	±15 µm	
	Calibrated	±1 µm	±1 μm	±1 μm	±1.5 µm	±1.5 μm	±2 μm	±2 μm	
Resolution (Min. Incremental Motion)		0.1 μm <sup>(2)</sup> ; 1.0 μm <sup>(2)</sup>							
Bidirectional Repeatability <sup>(1)</sup>			±1 µm						
Horizontal Straightness <sup>(1)</sup>		±2 μm	±2.5 μm	±2.5 μm	±3.5 μm	±4.5 μm	±5.5 μm	±6.5 µm	
Vertical Straightness <sup>(1)</sup>		±2 μm	±2.5 μm	±2.5 μm	±3.5 μm	±4.5 μm	±5.5 μm	±6.5 µm	
Pitch		27 µrad	29 µrad	40 µrad	50 µrad	60 µrad	70 µrad	80 µrad	
Roll		27 µrad	29 µrad	40 µrad	50 µrad	60 µrad	70 µrad	80 µrad	
Yaw		27 µrad	29 µrad	40 µrad	50 µrad	60 µrad	70 µrad	80 µrad	
Maximum Speed <sup>(4)</sup>		300 mm/s							
Maximum Acceleration <sup>(4)</sup>		Function of Motor and Amplifier Selection							
Load Capacity(5)	Horizontal	60 kg							
	Vertical (Axial)	50 kg							
	Side	60 kg							
Moving Mass		3.7 kg							
Stage Mass (No Motor)		11.2 kg	12.0 kg	12.8 kg	14.6 kg	16.3 kg	18.1 kg	19.9 kg	
Material			Anodized Aluminum						
MTBF (Mean Time Between Failure)			20,000 Hours						

Notes:

1. Certified with -PL1/PL2 options.

2. Achieved with Aerotech rotary motor with amplified sine encoder.

3. Achieved with Aerotech rotary motor with 2500 cnts/rev digital encoder.

4. Requires the selection of an appropriate amplifier with sufficient voltage and current.

5. Axis-orientation for on-axis loading is listed.

6. Specifications are for single-axis systems measured 25 mm above the tabletop. Performance of multi-axis systems is payload and workpoint dependent. Contact factory for multi-axis applications.

7. Specifications listed are for non-foldback kit options. Contact factory for specifications when a foldback kit (-FBx) is used.

Electrical Specifications				
Drive System	Brushless Rotary Servomotor			
Feedback (Rotary Encoder) <sup>(1)</sup>	Incremental – 1000 lines/rev (1 Vpp) and 2500 lines/rev (TTL)			
Maximum Bus Voltage	340 VDC			
Limit Switches	5 V, Normally-Closed			

1. Requires the selection of a motor option.



#### **PRO190SL ORDERING OPTIONS**

#### Travel (Required)

- -100 100 mm travel stage
- -150 150 mm travel stage
- -200 200 mm travel stage
- -300 300 mm travel stage
- -400 400 mm travel stage
- **-500** 500 mm travel stage
- -600 600 mm travel stage

Other travel options are available upon request. Contact Aerotech for more information.

#### Tabletop (Optional)

- -TT1 Tabletop with metric dimension mounting
- Note: TT option required for lower axis of XY when a foldback kit is used.

Other tabletop options are available upon request. Contact Aerotech for more information.

#### Motor (Optional)

- -M5 BM130 brushless servomotor and 2500-line TTL encoder
- -M6 BM130 brushless servomotor, 2500-line TTL encoder, and brake
- -M7 BM130 brushless servomotor and 1000-line 1 Vpp encoder
- -M8 BM130 brushless servomotor, 1000-line 1 Vpp encoder, and brake

Other motor options are available upon request. Contact Aerotech for more information.

#### Foldback (Optional)

-FB3 Foldback kit for 0.375 inch diameter shaft NEMA 23 motor

#### Motor Orientation (Optional)

- -2 Bottom cable exit, optional orientation
- -3 Left-side cable exit, standard orientation
- -8 Right-side foldback, standard orientation

Other motor orientation options are available upon request. Contact Aerotech for more information.

#### Limits (Required)

-LI1 Normally-closed limit switches; 5 VDC with 9-Pin D connector

Other limit options are available upon request. Contact Aerotech for more information.

#### Coupling (Optional)

-CP2 Coupling for 0.375 inch diameter shaft

Other coupling options are available upon request. Contact Aerotech for more information.

#### Lifting Hardware (Optional)

#### -LF Lifting hardware

Note: Lifting option only available on travels 400 mm and greater. Lifting should never be ordered on the upper-axis of an XY set (only order on lower-axis).

#### Metrology (Required)

- -PL0 No metrology performance plots
- -PL1 Metrology, uncalibrated with performance plots
- -PL2 Metrology, calibrated (HALAR) with performance plots



#### **Integration (Required)**

Aerotech offers both standard and custom integration services to help you get your system fully operational as quickly as possible. The following standard integration options are available for this system. Please consult Aerotech if you are unsure what level of integration is required or if you desire custom integration support with your system.

#### -TAS Integration - Test as system

Testing, integration and documentation of a group of components as a complete system that will be used together (ex: drive, controller and stage). This includes parameter file generation, system tuning and documentation of the system configuration.

#### -TAC Integration - Test as components

Testing and integration of individual items as discrete components. This is typically used for spare parts, replacement parts or items that will not be used or shipped together (ex: stage only). These components may or may not be part of a larger system.

#### Accessories (To Be Ordered As Separate Line Item)

ALIGN-NPA	Non-precision XY assembly			
ALIGN-NPAZ	Non-precision XZ or YZ assembly			
ALIGN-PA10	XY assembly; 10 arc sec orthogonality. Alignment to within 7 microns orthogonality			
	for short travel stages.			
ALIGN-PA10Z	XZ or YZ assembly with L-bracket; 10 arc second orthogonality. Alignment to			
	within 10 microns orthogonality for short travel stages.			
ALIGN-PA5	XY assembly; 5 arc sec orthogonality. Alignment to within 3 microns orthogonality			
	for short travel stages.			
ALIGN-PA5Z	XZ or YZ assembly with L-bracket; 5 arc second orthogonality. Alignment to within			
	5 microns orthogonality for short travel stages.			
HDZ190	Right angle L-bracket for PRO190SL-100 and PRO190SL-150 only.			
Note: HDZ190 requires a tabletop when mounting to a PRO series stage.				



#### **PR0190SL SPECIFICATIONS**



Cantilevered load capability of the PRO190SL.



aerotech.com

#### **PR0190SL DIMENSIONS**



DIMENSIONS: MILLIMETERS





